
### KV-K21MN11/K25MN11 RM-845T KV-K29MH11/K29MN11

### **SERVICE MANUAL**



### ME Model

RM-845P

KV-K21MN11 Chassis No. SCC-G37B-A KV-K25MN11 Chassis No. SCC-G37A-A

HK Model

KV-K29MH11

Chassis No. SCC-G43A-A

GE Model

GE IVIOGEI KV-K29MN11 Chassis No. SCC-G44A-A

EX Model KV-K21MN11 Chassis No. SCC-G50A-A KV-K25MN11 Chassis No. SCC-G50B-A

G3F CHASSIS

MODELS OF THE	SAME SERIES
KV-K21MN11/K25MN11 KV-K29MH11/K29MN11	



TRINITRON. COLOR TV

### **SPECIFICATIONS**

Specifications	KV-K21MN11	KV-K25MN11	KV-K29MN11 KV-K29MH11	Note
Power requirements	110-240 V AC, 50/60	Hz		
Power consumption (W)	135	165	171	
Television system	B/G, I, D/K, M			
Color system	PAL, PAL 60, SECAN	M, NTSC4.43, NTSC3.5	8	
Stereo system	NICAM Stereo B/G,	I ; A2 Stereo (Germany	y) B/G	
Channel coverage B/G		IF : E21 to E69 / CATV	: S01 to S03, S1 to S41	
1	UHF: B21 to B68			
D/K	VHF: R1 to R12 / U			
M	VHF: A2 to A13 / U A-8 to E, G to W+25,			
Antenna	75-ohm external ante	enna terminal for VHF,	/UHF	
Audio output (speaker)	7W × 2	13W × 2	13W × 2	
Number of terminal Video Audio	Input:3 Output:1			
S1-Video	Input: 2			Y: 1 Vp-p, 75 ohms, unbalanced, sync negative C: 0.286 Vp-p, 75 ohms
Picture tube		Super Trinitron		
Tube size (inch)	21	25	29	Measured diagonally
Screen size (cm)	54	60	68	Measured diagonally
Dimensions (w/h/d, mm)	550 × 455 × 473	619 × 514 × 500	694 × 578 × 527	
Mass (kg)	25.5	37.5	50	
Accessories Supplied	Remote commander	(1)		
	Size R6 (AA) battery	(1)		
Optional	Magic commander R		SU-K1G	

Design and specifications are subject to change without notice.


Sony Corporation Tokyo, Japan

### CAUTION

SHORT CIRCUIT THE ANODE OF THE PICTURE TUBE AND THE ANODE CAP TO THE METAL CHASSIS, CRT SHIELD, OR CARBON PAINTED ON THE CRT, AFTER REMOVING THE ANODE.

### SAFETY-RELATED COMPONENT WARNING!!

COMPONENTS IDENTIFIED BY SHADING AND MARK A ON THE SCHEMATIC DIAGRAMS, EXPLODED VIEWS AND IN THE PARTS LIST ARE CRITICAL TO SAFE OPERATION. REPLACE THESE COMPONENTS WITH SONY PARTS WHOSE PART NUMBERS APPEAR AS SHOWN IN THIS MANUAL OR IN SUPPLEMENTS PUBLISHED BY SONY.



### 1-1. HOOKING UP

# Connecting a ViF attents of a combination WEIGHF antenna

- 75-other countil cable (nound)

Attachunopismal EC setera omecur to the Socker resold office. Ray be connected into the T present/socket stiffer and of the TV.


No. of



崮

## Hosking up to aptional equipment

Not an exercit system and such Jodes equipment to the IV such as a VCR, main that physic, competite, to object on almost system.



When connecting a movement WER Connection place plug to PERO and the backgroup in INDEAL prints.

Place Strike and ride right as input as interest Let Strike against a strike letter of the second strike the second the Strike second se.

Notice on the DA Wilder right of the AMEDIA Low Manuscriptors and AMEDIA STATE AND AMEDIA AND AMEDIA

Ratio on the rideo imput When a age is 1916, first

### 3 Presidente Proces. 1-2. PRESETTING CHANNELS

□ ↑ ※※※

No.C

You are present IV thousake saidy by storing all the recolodis thousake assumatically. No can do present thousake recountly at studies program providens.

To start presetting channels automatically from the specified pregram position.

These thicklist POSET.

Press POSETBIRD soles you lost This primm.

These POSE ALTO MICE.

These ALTO MICE.

Technopolite pogram position has a chosend or to receive a diseased with a work-signal, proper the Presetting channels manually

Fources proact up to 198 TV channels in numerical

Presetting channels automatically

## Stample: In preset a chaesed in program position it

Z President - until 1º aprens Press MANUAL PRESET.

## 3 hour TESYSTEM to select your TV system.

ě Ô

-

800000

4 Press - or - until the charted you want

### 5 Press MANUAL PRESST.

Naprest other chamsels Especial others | Inch.

### The sole mitter picture may be pour and/or the sound may be many. In this start, which the appropriate TV spoken. of the Til system is not properly selected

Hear PECCE - 1--to-soled the program position.
 Hear IV SESTEM-and the picture and second.

When the TO's in standby mode after preseng MAIN POWER, prese/FOMER, on the Tries worder

P

Press MAIN POWER.

2 Press Tri SESTEM to ached your local TV




\*

100

Meta.

- Technique to T19/500 innoversal break payant prison.



### 1-5. WATCHING THE TV

## Press MAIN POWER to turn the TV on.

When the TV's instandly mode after pressing MAIN INDWEL press TORERS on In TV or smole

## 2 Selectifies IV chancelyma went to watch.

To salvett a channel directly. They is repries button.



To exhelic two digit channel, press "-/--" before the number bullots. Face example: to select channel 25, press "-y--,-





### Switching off the TV

Musing the sound

Pres MITTING

To evolution the TD temperating press PUPRES.



To evidence the TV completely, press MAIN POWER.
When the costs power is broaded all; the SIAMORY
indicates may lightery larg.

Displaying on-screen information

Press DESPERATORL

### Watching the video input.

PROFESSION NAMED IN COLUMN TWO IS NOT THE OWNER. THE OWNER. THE OWNER.



T ....

### To watch TV, press TV.

You can set the TV to home oil to be largeth at time you specify objects Settling the Sleep Timer

Press SLEEPWORK,

## Switching back quickly to the previous diamed


Press June?



To cased the Skep Times, prest SEE/VINDER
represely; and "SLEE OFF" appear, actions for TV
oil.

## 1-6. SETTING THE RENOTE COMMAND MODE

Bound use the rapping and motor community to operate the Toron Yang Say without paying the Act on a Toron without paying the Act on a Toron with the payers. To operate Says whose spacement, lets an the carelle community mode for the risker rapid mode for went to use.




### Three and hold the HOWER butto

## 2. Ives the number badtane that correspond to the remain correspond

Market Rooms	Sensite command mode
	TEM by Benforserville
-	1002 big. Americans (UCA)
111	VED by 1005 Served VCR)
*	Delight (meditiolise) (copyed)

Altersetting the remake communicately, you can see the following buttoon to operate the rideo oppopment.



# 1-7. ADJUSTING THE PICTURE Adjusting the picture precisely

You can object the picture quality persisting with the ADDERWENT option. The adversed actings are store to the PERSONAL option.

### These MEMI.

2 Press do of 7- to move the cursor (b) to VIDEO (CONTROL, and press EMER.

3 Press 6+ or 9- to move the cursor (9+ to Advissible), and press BHBB.

A Present or 7- to move the cursor (b) to the idea you want to adjust, and press ENTER.

Villabora Atlanta in VI LTARE SERVICE IN SALES SERVICE SERVICE IN SALES SERVICE SERVICE IN SALES SERVICE SERVICE IN SALES SERVICE SERVICE SERVICE IN SALES SERVICE S

PY TOES CONTROL AUDIO CONTROL SET W CASCASS

These MENU.

5 from the or 7 to adjust the item, and press EINES.

Press 2+ on %- to move the cursor (P) to VIDIO CONTROL.

NAME AND ASSESSED.

20100

STREET, STREET

## If the color of the picture is abnormal. When posture throughter I became in the TYSTEM of COLOR SYSTEM and the color become recent.

1-8. ADJUSTING THE SOUND



ė.	ě		
ř	4	J	

	٦	
	J	
	1	#
	1	
37	J	2
5 A.	1	8
tillä.	1	ž
80 M (I)	_)	-

ACCURATION CONTROL	- AMERICA III	200	CLEAN AND AND	- CONTROL -	THE PERSON NAMED IN
100	7	2	-	*	

## 4 Press 2+ Or T-16 polect the second that you went, and press BMBH.

Sedenti	4
MUSIC.	Lectes to entities probjective.
543	Listen in news program, A general viscolor person's various can be brand should
CANDARD	Cottos in grand-other than select of cores.
FRANKET.	Licker to the sound that is adjusted soing AUTIST WING.
THEMESTIC	Maker specific sellings. See

## 5 Press MENS to return to the normal screen.

- dischipythe

	100
	Post
	856
	SECO
	事者
N.	a Norma

### 1 Press Milwu.

Ø.	1	7	

ACTION CONTROL

Š	
i	
Ī	
ģ	d
į,	Ě
á	8
100	簽

11250 0387150, 1250 0387150, 257 18\* 12409406

2 mg (5)

### 3 Presidentes.

R	1	8	

6 To adjust other hems, repeat steps 4 and 5. 7 Frest MEMB to return to the normal screen.

4 Press as or 7- to select the setting, and press BITEs.

Topic .

SECOL Digital Reference

3 headenter.

25,5487

V 1050 CONTAGL POTAGE C W-55A P SOFT JOSEPHAN MOLATINEST

AGENT COMPTION	2197	CLINE AND	#DRODOWAL #Christmens	
6	14		)	

ģ

Ę

5 Prus MENU to return to the normal screen.

ACMINISTRADE. PASSON

90

### Adjusting the sound precisally

You paradipat the sound persiety with the ALRICENEET opera. The adjusted settings are extend in the PERSONAL spine.

### The second

- 2 Press 2+ or 9-16 move the consor(Pt) to Author CoATROL, and press ERTER.
- 3 Presi d+ at P-15 move the consentity to Applicability and presi BMRs.
- A threat as at 7-15 move the carson (P-14s the items powers and in adjust, and press ENTR.

Preza ARBEM ARRE repented from reacher the second year wear.
The second charges and the mempeoding indicator lights up as follows:

_

5 Press du or R- to adjust the loss, and press BATER.

8-0-K

į		Present Firms
89		Decrease the loss sound
37000	E Increase the teshi- sound	Decream the traffic sound
E SERVICE		househorshors digitalisation

When the String is NUCAM program

## 6 To adjust other items, repeat steps 4 and 5.

A A I I Again day - personal - lings

SECMEN MICAN

MCAMPhigas

NACAM Home

- See - Sept

7 Press MEMI to return to the months passed Measurement programs through the T learning throat TI SESTEM and the round becames them. If the sound is distorted on noisy

When many to M. Comment program

Section 1



100 mm

Al Commel

## Baceloing area for MCRM and AD [German] programs

1-9. SELECTING A STEREO OR

BILINGUAL PROGRAM

Maring areas	Office Stage
-	2
Special Control	MEAN

Residency area	New Josians, Shappon, New Josians, etc.	Assembly, Nationals, The Book of
System	MCAN	Ad (Commen)


You can enjoy stems sound or Mingood program of NGCAH and AZ (Common) systems. The Indial serface in

Managharing areas	New Dalant, Singapo New Dalant, etc.	Acceptable Michigals, The Book of
Lugar	NYCH.	( Deman)

### 1-10. WATCHING TWO PICTURES SIMULTANEOUSLY


### Transcription (SESSERIC DECEMBER 1 and

(Wherein joint peture) within the mongature of a perjument. It pregram on a video input. With the hardways a on thipky a Potent in Total



### Displaying PIP

### Peter Pin.



The charters are displayed as follows: White screen, green

mental violes, press VIDSO/1900, in sent a mideo Wileding a TV program or sideo in the main its adjects TV program, pros TV and solved the

## Selecting a TV program or video in the PIS

the select the theorem. In select wides, press VDEO/VIOLD to select twides selects TV program, press TV/VDBD to select TV

- Transmitteling different IV progresse sides to VCD i ball-ballower

ž

9

1


## Swapping pictures betaveen the main and PIP screens

1-11. VIEWING TELETEXT



## Changing the position of the PIP screen

### Fress, POSITION.



### Freezing the PIF screen

### Preside Still Size.

normal picture, porce PRESES again. To resident the

- Please you display a VAI pointer on the TIT section of a speed of the filter meaning sold. The politics may be still a speeding on the VAI. The politic can be impossed by selecting the service MOL The picture can be serviced the PC server.
- If you display delicent is were present (P.M., Ph.). SELECTAR, If you display delicent is well as PET server, the size of the PETAL or the male excess and the PET planes, the size of the The borne into the delicent and the PET planes may be made. This is not cancelly the analyses of the PET.

## Checking the contemts of a teletrart

Press SLEEPINDEX to display an everylear of

### Using fastent

This became allows you to quickly access a referent page. index. These color humans function as the fastest that each based. When a locked page is broadcast, a male cooking mean agreem of the feature of the enven The colors of the energy consequent to the IEE. CREEM, YELLOW, and CYMN between on the sensor. buttons in belefied made.

matches page any expedient functority or moves at any

Telefox I service allows you to receive harines

TV stations have does an information service called referent via a TV demand.

## Press the color batton which corresponds to the color-coded menu. The page is displayed after a few records.

### Selecting a trafetent page

To input the three-digit page number of the teletrat page, press the number buildons. If you have mole a missie, by in the count page.

### to access the next or previous page, prest

### Holding a teletext page

Z Press IECT to display the teletion: A related page is display the teletion in the index page. If there is no indexer broadcas, \$100 is displayed at the tag lich come of the sones.

cancel the telebrah display, pass, TV.

Select a TV channel which carries the teletratibroadcast you mant to match.

Displaying telebeat

A beleton page may coosis of several pulpages. You constep the page scrolling in order to read the text at PRICE VIDEDISOLD. The part part

The HOLD symbol "(SF is displayed at the top left content of the scene).

Superimposing a telefant page on the

Both time you press TEXT, the somes changes as

Personal SECUL

VT+- Tribute trades -- Trades

To resume macmal teletient operation, press

Semetians pages contribr concealed behaviour, such as an assess to a quit. The treed option lets you decide the inferior the form

Renealing concealed information

### Page DESPRESSAL

Doorneal the Information, peen USP/15/15/1541, again.

### Enlarging the teletext display

### PRESS ARRENCANCE.

Such firms you person A.T.D. Exit.ARCE, they hald not display of damper an Editoric

### Ť Date Black

### Waiting for a toletoxt page while watching a TV program

Key in the page number of the teletral that you want to rafer, then press TIMERUT CLR 2 When the page number is displayed on the screen, peek TEXT to switch the belefast on

### 9

'n

## 1-12. CUSTOMIZING THE

### TV (SET UP)

## Using the AV OUT (advanced recount) terminal

Nonconsiders for subject righted from the MCMATFF - OLD judgest the own of the TV is the TV righters the agend of the parametryou and wanding and months.

## Press MENT.

## Z Press 2x or 7x to select SET UR, and press ENTER.

When sections; the agend conducting to wide mode (5). Takes agend, you can change the sheed for

picture in the scores.

Setting wide mode

	_
ž.	
8988	
18	
****	1000

ŧ		
Ī		
ğ		
ž.		
ł		
ä		
8		
4	Ħ	
I	ī	
m		

4. Press Lever 7- to select the output signal, and green BITES.

	No.	of the place.
	Company the Physics	Output the riginal
Select.	TV.	MCMUTOR

		No.	de la
100	Output the Philipped.	Output the riginal of the use extending as amonth	Accept in reading to the second of the secon
	114	MCM/TOB.	No. of the control of

### Selecting the sumound sound

Adjusting the Elit of the picture # EP-423-BATTE 258-FET Only

You can expy in commend about direct that is like helpy in a mask half when receiving about algority.

You can edget the tilt of the place of it is not aligned to the IV screen. This happens when you set the IV is technology when you set the IV is technology with effect of magnetic fields.

### 1 Pres HENL

2 heads or to be select SET US, and press DRIBA.

Three MENU.

ī	
1	
1	
١	
١	6956
-	11.00
Į	* 0 Kg
-1	P-1255
-	10160
- 1	表演与表示

2 Press du or Tu-to celect EET IR, and press BRIER.

## 3 has to or E-to select SURBOINE, and press BVIR.

4 Press du or 15- to tarm the sumound sound

on an off, and press BRIES

	report and the to	nordered for its normal rights	ment spand
£	Univer to see	Lister brase effective lan	The second
Selection of the last	ð	Sawa	EED

4 Press as or 7- to salect the most suitable value to align the picture position.

3 heat to or 1- to select TLI CORRECTOR, and proceSMSA.

### Reducing the noise of the picture

You can reduce the rooks level stiffle plotters when the IV excitors a west appeal or when you play a redesting what is in poor condition.

### Personal Marketine

Z Immate or 1- to select SEI UP, and press

8	
5855	
1.500	
1111	

When the set V. to select WHIS Mit, and

Digital for pictors in the series in with resolution the estimate when reasoning the CS-Video ingraf frough the CS-Video input just.

b

Dapley fle pickers on flexones in without the

To all the MATTE

ě

4. Design up on 7. Its select the relationship to suit the size of the picture you went to simpley on the TI somen.

Sees to pr 7- to select WDC, and press

4. From the pr 7- in turn the noise reduction on or eith, and press BVIBS.

Mean trapicament and identification for length intervelop or and includeding the CVT experience interlugence of the tra-al the screen.

I frees to or T-december SELUF, and press

Then Miles

### Anditional information

## 1-13. TROUBLESHOOTING

Seed picture Moley sound

below.

It for problem possion, contract point marrier synfactured survey marrier or develop. If positions any problem, and the named again and check the communication for each symptom behalf

Steamy picture Roley yeared

◆ Dark the attent.

◆ Dark the selection of he TV

and on he well.

◆ Dark the TV pages white.

Detred first or shipes



The may be present by form it interferences one area, now region have driven, refu.).
 Algorithm armony for management interference.

Double images or 'shoots'



This may be council by reflections from reaction measurable as buildings. A highly disectional authors. Dog improve for private.

+ Check for TV SYSTEM Works W.

President ROWER
 President ROWER
 Oaks he wise committee
 Oaks he W. Eversetter.


+ Presidente.
+ Presidente.
- Presidente.
- Presidente.

i d


Adjust the CCLASS level in the VQSS2 CONTROL owners Adjustifically opines.
 Oberts the COLDS SYSTEM setting.

### SECTION 2 DISASSEMBLY


### 2-1. REAR COVER REMOVAL (KV-K21MN11 only)




### 2-1. REAR COVER REMOVAL (KV-K25MN11/K29MN11/K29MH11 only)




### 2-2. SWITCH BLOCK REMOVAL




### 2-3. SPEAKER REMOVAL




### 2-4. CHASSIS ASSY REMOVAL




### 2-5. SERVICE POSITION




### 2-6. EXTENSION CABLE



### 2-7. DEMAGNETIZATION COIL REMOVAL




### 2-8. PICTURE TUBE REMOVAL




### • REMOVAL OF ANODE-CAP

Note: Short circuit the anode of the picture tube and the anode cap to the metal chassis, CRT shield, or carbon painted on the CRT, after removing the anode.


### • REMOVING PROCEDURES



① Turn up one side of the rubber cap in the direction indicated by the arrow ⓐ.



② Using a thumb pull up the rubber`cap firmly in the direction indicated by the arrow ⑤.



③ When one side of the rubber cap is separated from the anode button, the anode-cap can be removed by turning up the rubber cap and pulling up it in the direction of the arrow ⑥.


### • HOW TO HANDLE AN ANODE-CAP

- ① Don't hurt the surface of anode-caps with sharp shaped material!
- ② Don't press the rubber hardly not to hurt inside of anode-caps! A metal fitting called as shatter-hook
- terminal is built in the rubber.

  ③ Don't turn the foot of rubber over hardly!


  The shatter-hook terminal will stick out or hurt the rubber.






### 2-9. HARNESS LOCATION


### (1) TOP VIEW




### (2) TOP VIEW (LEFT)



### (3) LEFT SIDE VIEW



### (4) RIGHT SIDE VIEW



### **SECTION 3**

### **SET-UP ADJUSTMENTS**

- The following adjustments should be made when a complete realignment is required or a new picture tube is installed.
- These adjustments should be performed with rated power supply voltage unless otherwise noted.

Controls and switch should be set as follows unless otherwise noted:

PICTURE control . . . . . . . . . . RESET BRIGHTNESS control

Perform the adjustments in order as follows:

- 1. Beam Landing
- Convergence
- 3. Focus

4. White Balance

Note: Test Equipment Required.

- 1. Color-bar/Pattern Generator
- 2. Degausser
- 3. Oscilloscope

### Preparations:


- In order to reduce the influence of geomagnetism on the set's picture tube face it east or west.
- Switch on the set's power and degauss with the degausser.


### 3-1. BEAM LANDING

- Input the white signal with the pattern generator. Contrast normal **Bightness**
- 2. Position neck ass'y as shown in Fig 3-2.
- Set the pattern generator raster signal to red.
- 4. Move the deflection yoke to the rear and adjust with the purity control so that the red is at the center and the blue and the green take up equally sized areas on each side.

(See Figures 3-1 through 3-3.)

- 5. Move the deflection yoke forward and adjust so that entire screen is red. (See Figure 3-1.)
- 6. Switch the raster signal to blue, then to green and verify the condition.
- 7. When the position of the deflection yoke has been decided, fasten the deflection yoke with the screws.
- 8. If the beam does not land correctly in all the corners, use a magnet to adjust it. (See Figure 3-4.)










Fig.3-3



### 3-2. CONVERGENCE

### Preparation:


- Before starting this adjustment, adjust the focus, horizontal size, and vertical size.
- Minimize the brightness setting.
- Provide dot pattern.
- (1) Horizontal and Vertical Static Convergence




- (Moving horizontally), adjust the H.STAT control
  so that the red, green, and blue points are on top
  of each other at the center of the screen.
- (Moving vertically), adjust the V.STAT magnet so that the red, green, and blue points are on top of each other at the center of the screen.
- 3. If the H.STAT variable resistor cannot bring the red, green, and blue points together at the center of the screen, adjust the horizontal convergence with the H.STAT variable resistor and the V. STAT magnet in the manner given below.

(In this case, the H.STAT variable resistor and the V.STAT magnet influence each other)


 Tilt the V.STAT magnet and adjust the static convergence by opening or closing the V.STAT magnet.



4. If the V.STAT magnet is moved in the direction of the and arrows, the red, green, and blue points move as shown below.




• Operation of BMC (Hexapole) Magnet




 The respective dot positions resulting from moving each magnet interact, so be sure to perform adjustment while tracking.
 Use the H.STAT VR to adjust the red, green, and blue dots so they coincide at the center of screen (by moving the dots in the horizontal direction).

### (2) Dynamic Convergence Adjustment Preparations:


- Before starting this adjustment, adjust the horizontal static convergence and the vertical static convergence.
- 1. Slightly loosen the deflection yoke screws.
- 2. Remove the deflection yoke spacer.




- · Y separation axis correction magnet adjustment
- Receive the cross-hatch signal, and adjust [PIX] to "MIN" and [BRT] to "standard".
- 2. Adjust the deflection yoke to the upright condition when it hits the CRT.
- 3. Adjust so that the Y separation axis correction magnet on the neck assembly is symmetrical at the top and bottom (open state).
- 4. Return the deflection yoke to its original position.
- 3. Move the deflection yoke as shown in the figure below and optimize the convergence.
- 4. Tighten the deflection yoke screws.
- 5. Install the defelection yoke spacer.




### (3) Screen-corner Convergence





### 3-3. FOCUS ADJUSTMENT

Adjust FOCUS control on the flyback transformer for a best focus.



### a. AN ITEM OF ADJUSTMENT

ltem number	Adjustment	St	andard			
	•	50 H	Iz	60 H	łz	Note
number	item	Normal	Wide	Normal	Wide	
07	GDR	1F	1F	1F	1F	G Drive
08	BDR	1F	1F	1F	1F	B Drive
09	GCT	07	07	07	07	G CUT-OFF
0A	BCT	07	07	07	07	B CUT-OFF
05	SBR	1F	1F	1F	1F	SUB-
						BRIGHTNESS

### b . METHOD OF CANCELLATION FROM SERVICE MODE


Set the standby condition (Press POWER button on the commander) in the next place, press POWER button again, hereupon it becomes TV mode.

### c. METHOD OF WRITE FOR MEMORY

- 1) Set to Service Mode.
- 2) Press [1] (UP) and [4] (DOWN), select an item of adjustments.
- 3) Press MUTE button indicate WRITE (RED) on screen.
- 4)Press button to write for memory.

### d. MEMORY WRITE CONFIRMATION METHOD


- 1) After adjustment, pull out the plug from AC outlet, and next place, plug in AC outlet again.
- Turn the power switch ON and set to Service Mode.
- Call the adjusted items again, confirm they were adjusted.



### 3-4. G2 (SCREEN) AND WHITE BALANCE ADJUSTMENTS

### 1. G 2 (SCREEN) ADJUSTMENT(RV 701)

- 1) Set the PICTURE and BRIGHTNESS to normal.
- 2) Put to VIDEO input mode without signals.
- 3) Set to Service Mode.
- 4) Change BLU data of the item number "57" from "01" to "00". (To turn off Blue Black.)
- 5) Press MUTE, and 0 to write the data in the memory.
- 6) Connect R, G, and B of the C board cathode to the oscilloscope.
- 7) Adjust G2 (RV701) volume to the value below.



- 8) Re-set BLU data of the item number "57" from "00" back to "01".
- 9) Press MUTE, and 0 to write the data in the memory.


### 2. WHITE BALANCE ADJUSTMENTS

- 1) Set to service mode.
- 2) Input an entire white signal.
- 3) Set the PICTURE to minimum.
- 4) Select SBR with 1 and 4, and then set the level to minimum with 3 and 6
- 5) Select GCT and BCT with 1 and 4.

  And adjust the level with 3 and 6 for the best white balance.
- 6) Set the PICTURE to maximum.
- 7) Select GDR and BDR with 1 and 4 and adjust the level with 3 and 6 for the best white balance.
- 8) Write into the memory by pressing  $\overline{\text{MUTE}} \rightarrow \text{then } \boxed{0}$ .

### 3. SUB BRIGHT ADJUSTMENT


- 1) Set to service mode.
- 2) Input a staircase signal of black and white from the pattern generator.
- 3) BRIGHTNESS ··· RESET PICTURE ······· minimum
- 4) Select SBR with land 4, and adjust SBR level with 3 and 6 so that the stripe second from the right is dimly lit.





### SECTION 4 CIRCUIT ADJUSTMENTS


### 4-1. ADJUSTMENTS WITH COMMANDER


Servise adjustments are made with the RM-845 that comes with this unit.












### 4-2. ADJUSTMENT METHOD


**Item Number 24** 

This explanation uses V-SHFT as an example.


- 1. Select 24 V-SHFT with the "1" and "4" buttons.
- 2. Raise/lower the data with the "3" and "6" buttons.
- Select the optimum state. (The standard is for 0F PAL reception.)
- 4. Write with the MUTE button. (The display changes to blue WRITE.)
- 5. Execute the writing with the "0" button. (The WRITE display changes briefly to red.)



Adjusted with "3" and "6" buttons



Written with "MUTE"



Write excuted with "0"

Use the same method for Items Number 00-5E. Use "1" and "4" to select the adjustment item, use "3" and "6" to adjust, write with "MUTE", then execute the write with "0".

Note: In "WRITE", the data of all items are wrote together to memory.

- H-FRE can be adjusted automatically. Feed a standard signal and input "9", the automatic adjustment is executed.
- As for V-FREQ, by searching the bolded screen V range with adjusting data.

Note: In item 02 50Hz, or item 03 60Hz, it operates normally in spite of the 50Hz or the 60Hz of the input signal. Therefore be sure to adjust data according to the input signal.

				Standar	d DATA				
Item	l llata		50 Hz		60 Hz		Note	(Device)	
number	Item		Normal	Wide	Normal	Wide		,	
00	RGB	00~0F	07	07	07	07	RGB PICTURE	(CXA 1587 S)	
01	SCN	00~0F	08	06	08	06	SUB-Contrast	(CXA 1587 S)	
02	VM	00~03	02	02	02	02	VM Level	(CXA 1587 S)	
03	SCL	00~0F	08	07	08	07	SUB-COLOR	(CXA 1587 S)	
04	SHU	00~0F	08	08	08	08	SUB-HUE	(CXA 1587 S)	
05	SBR	00∼3F	1F	1F	1F	1F	SUB-BRIGHTNESS	(CXA 1587 S)	
06	ABL	00~03	03	03	02	02	ABL Mode	(CXA 1587 S)	
07	GDR	00∼3F	1F	1F	1F	1F	G Drive	(CXA 1587 S)	
80	BDR	00∼3F	1F	1F	1F	1F	B Drive	(CXA 1587 S)	
09	GCT	00~0F	07	07	07	07	G CUT-OFF	(CXA 1587 S)	
0A	BCT	00~0F	07	07	07	07	B CUT-OFF	(CXA 1587 S)	
0B	AKR	00∼FF	7F	7F	7F	7F	AKB OFF R CUT-OFF	(CXA 1587 S)	
0C	AKG	00~FF	7F	7F	7F	7F	AKB OFF G CUT-OFF	(CXA 1587 S)	
0D	AKB	00∼FF	7F	7F	7F	7F	AKB OFF B CUT-OFF	(CXA 1587 S)	
0E	GMA	00~0F	0C	0C	OC	0C	$\gamma$ control	(CXA 1587 S)	
0F	DCT	00~03	00	00	00	00	DC TRAN	(CXA 1587 S)	
10	DPI	00~03	03	03	03	03	D-PIC	(CXA 1587 S)	
11	YFI	00∼3F	22	22	22	22	Y Filter Adjust	(CXA 1587 S)	
12	SHL	00~01	01	01	01	01	SHP-LIM	(CXA 1587 S)	
13	YDL	00~0F	07	07	07	07	Y Delay Time	(CXA 1587 S)	
14	YSW	00~03	01	01	01	01	Y-SW OUT	(CXA 1587 S)	
15	HSH	00∼3F	24	24	28	28	H Shift	(CXA 1587 S)	
16	POV	00~0F	08	08	08	80	Pre-Over	(CXA 1587 S)	
17	SHF	00~03	02	02	02	02	SHP-F 0	(CXA 1587 S)	
18	SSH	00~03	01	01	02	02	SUB-Sharpness	(CXA 1587 S)	
19	RMT	00~01 00~01	00	00	00	00	R-Mute	(CXA 1587 S)	
1A	GMT		00	00	00	00	G-Mute	(CXA 1587 S)	
1B	BMT	00~01	00	00	00	00	B-Mute	(CXA 1587 S)	
1C	AG 1	00~01	00	00	00	00	Aging 1 (White)	(CXA 1587 S)	
1D	AKF	00~01	00	00	00	00	AKB-OFF	(CXA 1587 S)	
1E	SMD	00~01	00	00	00	00	Scan Mode	(CXA 1587 S)	
1F 20	VEX	00~01	00	00 03	00	00	V-Extension	(CXA 1587 S)	
21	AFC AFF	00~03 00~01	03	00	03	03 00	AFC Loop Gain	(CXA 1587 S)	
22	RFP	00~01	00	00	00	00	AFC-OFF Reference Position	(CXA 1587 S) (CXA 1587 S)	
								,	
23	VSZ	00∼3F	1E	1E	1A	1A	V-Size	(CXD 2018 Q)	
24	VSF	00∼3F	2E	2E	32	32	V-Shift	(CXD 2018 Q)	
25	SCR	00∼F	80	08	80	80	S-Correction	(CXD 2018 Q)	
26	VLN	00∼F	80	08	80	80	V-Linearity	(CXD 2018 Q)	
27	HSZ	00∼3F	0C	0C	0 E	0 E	H-Size	(CXD 2018 Q)	
28	PAP	00∼3F	2E	2E	2E	2E	Pin-Amp	(CXD 2018 Q)	
29	TLT	00~0F	09	09	09	09	Tilt	(CXD 2018 Q)	
2A	UCP	00~0F	0A	0A	0A	0A	Upper Corner Pin	(CXD 2018 Q)	
2B	LCP	00~0F	0C	0C	0C	0C	Lower Corner Pin	(CXD 2018 Q)	
2C	VBW	00~0F	08	08	80	08	V-Bow	(CXD 2018 Q)	
2D	VAG	00∼0F	80	08	80	08	V-Angle	(CXD 2018 Q)	
2E	HVV	00~07	04	04	04	04	HV-Comp-V	(CXD 2018 Q)	
2F	HVH	00~07	00	00	00	00	HV-Comp-H	(CXD 2018 Q)	
30	FCL	00~07	03	03	03	03	Frame Color	(SDA 9188)	
31	FON	00~01	01	01	01	01	Frame ON	(SDA 9188)	
32	DLY	00~07	00	00	00	00	Select Delay LL 3 P	(SDA 9188)	
33	P-V	00~0F	07	07	07	07	V read delay	(SDA 9188)	
34	PVS	00~07	04	04	04	04	PIP-V offset	(SDA 9188)	
35	P-H	00~3F	0A	0A	07	07	H read delay	(SDA 9188)	
36	PHS	00~0F	07	07	03	03	PIP-H offset	(SDA 9188)	
37	CTR	00~0 F	0A	0A	0A	0A	Contrast	(SDA 9188)	
38	FWV	00~01	01	01	01	01	Frame Width V	(SDA 9188)	
39	FWH	00~01	01	01	01	01	Frame Width H	(SDA 9188)	
3A	DVI	00~0F	07	07	07	07	Setting Delay VSI	(SDA 9188)	
3B	DVP	00~0 F	0F	0F	0F	0F	Delay VSP Pulse	(SDA 9188)	
3C	BRT	00~0 F	0C	0C	0C	0C	Frame BRIGHT Data	(SDA 9188)	

	A 12			Standar	d DATA				
Item Adjustmer	Adjustment	1)ata range	50	50 Hz		Hz	Note	(Device)	
number	item		Normal	Wide	Normal	Wide		(=====)	
3D	LEV	00~0 F	00	00	00	00	Level Adjust	(TDA 9840)	
3E	STR	00∼3 F	02	02	02	02	Stereo Adjust	(TDA 9840)	
3F	AXG	00~01	00	00	00	00	AUX Output Gain	(TDA 8204)	
40	AXM	00~01	00	00	00	00	AUX Output Mute	(TDA 8204)	
41	VCX	00~01	00	00	00	00	VCXO free run	(TDA 8204)	
42	ERC	00~01	00	00	00	00	Error count Time	(TDA 8204)	
43	MXE	00~01	00	00	00	00	MAX. allowed Error	(TDA 8204)	
44	SRO	00~01	00	00	00	00	SRO set Bit	(TDA 8204)	
45	ATO	00~00	01	01	01	01	Auto Selection	(TDA 8204)	
46	SYS	00~01	00	00	00	00	System select	(TDA 8204)	
47	FSW	00~03	00	00	00	00	Force Switch	(TDA 8204)	
48	SYN	00~01	01	01	01	01	Synthesizer	(TDA 8204)	
49	VCR	00~01	00	00	00	00	VCC Reference Sw	(CXP 1315 P)	
4A	SEL	00~FF	5F	5F	5 F	5F	Separation Level	(CXP 1315 P)	
4B	DCS	00∼3F							
4C	UYB	00~3F							
4D	LYB	00~3F					•		
4E	HAP	00~3F							
4F	HTL	00~3F							
50	UCB	00~3F							
51	UTL	00~3F			l 1				
52	LCB	00~3F							
53	LTL	00~3F							
54	TXP	00∼0 F	00	00	00	00	Teletext Picture	(Teletext μ-Co	
55	ODL	00~FF	10	10	10	10	Power ON Delay	(CXP 80424)	
56	OSH	00∼3 F	OF	0F	0F	OF	OSD Position H	(CXP 80424)	
57	BLU	00~01	01	01	01	01	Blue Back Feature	(CXP 80424)	
58	ROC	00~0F	07	07	07	07	Center of Rotation	(CXP 80424)	
59	ROS	00~07	03	03	03	03	Step Width	(CXP 80424)	
5A	HTR	00∼3 F	1 F	1 F	1F	1 F	H Trapezoid	(CXP 80424)	
5B	MUT	00~01	01	01	01	01	No Sync. Mute	(CXP 80424)	
5C	DID	00~01	00	00	00	00	Disable Degauss	(CXP 80424)	
5D	OP0	00~FF	*1	*1	*1	*1	Option 0	(CXP 80424)	
5E	OP1	00~0F	*2	*2	*2	*2	Option 1	(CXP 80424)	

### \*1 Input data are different according to models.

İtem	CCD	Text	PinP	Jpn	NICM	W. G	мтѕ	Comb
KV-K21MN11	0	1	0	0	1	1	0	1
KV-K25MN11	0	1	1	0	1	1	0	1
KV-K29MN11	0	1	1	0	1	1	0	1
KV-K29MH11	0	1	1	0	1	1	0	1

### \*2 Input data are different according to models.

ltem	-	-	-	-	Mono	Tilt	Dcon	Chin
KV-K21MN11	0	0	0	0	0	0	0	1
KV-K25MN11	0	0	0	0	0	0	0	1
KV-K29MN11	0	0	0	0	0	1	0	1
KV-K29MH11	0	0	0	0	0	1	0	1

### **PICTURE QUALITY ADJUSTMENTS**

Numbers 03-05, 18

CL

HU

BR Set to the standard values.

SH

### **DISPLAY POSITION ADJUSTMENT**


Numbers 35-36

-V Pin-P vertical position correction

'VS Pin-P vertical offset

'-H Pin-P horizontal position correction

'HS horizontal offset



nen pressing PIP"POSITION" key in the vice mode, "POSITION" turns round and and automatically.

Numbers 33-36 are set to the standard values.


'XP Teletext picture orrects the brightness for when teletext is seeived.

tandard value is 05.


### 4-5. PICTURE DISTORTION ADJUSTMENT

Item Numbers 23-2D


23 VSZ (V SIZE)




24 VSF (V SHIFT)




25 SCR (VERTICAL S correction)




26 VLN (V LINEARITY)




27 HSZ (H SIZE)



28 PAP (PIN AMP)




29 TLT (TILT)




2A UCP (Upper Corner Pin)


2B LCP (Lower Corner Pin)




2C VBOW (V-BOW)




2D VAG (V-ANGLE)







SECTION 6
DIAGRAMS

### 6-1. BLOCK DIAGRAM






### 6-2. FRAME SCHEMATIC DIAGRAM



, •

### . CIRCUIT BOARDS LOCATION



### 6-4. SCHEMATIC DIAGRAMS AND PRINTED WIRING BOARDS

- All capacitors are in μF unless otherwise noted. pF: μμF 50 WV or less are not indicated except for electrolytic and
- All resistors are in ohms.

 $k\Omega = 1000 \Omega$ ,  $M\Omega = 1000 K\Omega$ 

· Indication of resistance, which does not have one for rating electrical power, is as follows.

Pitch: 5 mm Rating electrical power 1/4 W (CHIP: 1/10W)

- : nonflammable resistor.
- △ : internal component.
   □ : panel designation, or adjustment for repair.
- All variable and adjustable resistors have characteristic curve B, unless otherwise noted.
- Readings are taken with a color-bar signal input.

no mark: PAL

- ⟨ ⟩: SECAM
- ): NTSC 3.58
- ( ): NTSC 4.43
- Readings are taken with a 10 MΩ digital multimeter.
- Voltage are dc with respect to ground unless otherwise noted.
- · Voltage variations may be noted due to normal production tolerances.
- All voltages are in V.
- \* : Can not be measured.
- Circled numbers are waveform reference.
- : B + bus.
- === : B bus.
- : signal path.

Note: The components identified by shading and mark A are critical for safety. Replace only with part number specified.

### Reference information

RESISTOR : RN METAL FILM

: RC SOLID

: FPRD NONFLAMMABLE CARBON

: FUSE NONFLAMMABLE FUSIBLE

NONFLAMMABLE METAL OXIDE : RB NONFLAMMABLE CEMENT

NONFLAMMABLE WIREWOUND : RW

: ※ ADJUSTMENT RESISTOR

: LF-8L MICRO INDUCTOR

CAPACITOR : TA

COIL

TANTALUM : PS

STYROL : PP POLYPROPYLENE

MYLAR

: MPS METALIZED POLYESTER


: MPP METALIZED POLYPROPYLENE

BIPOLAR


: ALT HIGH TEMPERATURE

HIGH RIPPLE : ALR


### PRINTED WIRING BOARDS - F1 Board -




### - H1 Board -











- D Board -		
DIODE 1 2 3 4 5 6	7 8 9	10
D801 B - 4 D802 D - 4 D802 D - 4 D803 E - 2 D808 E - 2 D808 E - 2 D809 B - 3 D804 E - 1 D815 F - 2 D809 F - 8 D806 F - 8 D807 F - 8 D807 F - 8 D808 F - 8	SONY 1-649-204-21	T804  EY801  EY802  EY805  T804  EY805  L801  R1500  R1500  C1513  R1500  C1514  C1505  R1500  C1504  C1505  R1500

CN0506 \$ 2 2 3 4 5 5 4 7 4 7 4

CB42 4 CN0527 1

F 25 E

3 (01501) E

E R1512 1 CN518

NC NC NC NC NC NC NC NC NC NC

ed as left contains high voltage of over ist be paid to prevent an electric shock in

• D BOARD IC

B – 1


IC600 B - 1 IC601 B - 3 IC602 F - 1 IC804 F - 7 IC1501 E - 10


IC2504 E - 3


TRANSISTOR

Q600 C - 4 Q601 E - 1 Q602 E - 1 Q603 E - 1 Q604 F - 3 Q803 F - 6 Q1501 F - 9 Q1502 E - 9 Q1503 E - 9 Q1504 F - 9 Q2501 F - 4 Q2502 D - 5 Q2503 E - 4 Q2505 E - 4 Q2591 D - 6


IC303 IC600










8 | 9 | 10 | 11 | 12 | 13 | 14 | 15 | 16 | 17 | 18 | 19 | 20 | 21 | 22 | 23 | 24 | 25 | 26 | 27 | 28







### • D BOARD WAVEFORMS











#### agram of A Board

AVEFORMS	3		
	2	3 PAL SECAM NISCLAS	3 NTSC3.58
5 Vp-p (H)	2.0 Vp-p (H)	2.0 Vp-p (H)	1.75 Vp-p (H)
	(5)	(a)	7 PAL SECAM NTSOLAS
2.25 Vp-p (H)	2.25 Vp-p (H)	2.0 Vp-p	2.0 Vp-p (H)
NTSC3.58		9 PAL SECAM NTSC4.43	9 NTSC3.58
1.75 Vp-p (H)	1.2 Vp-p (H)	1.1 Vp-p (H)	0.8 Vp-p (H)
	minimi.		: Jmhhhr! 3
1.2 Vp-p (H)	0.8 Vp-p (H)	0.9 Vp-p (H)	0.8 Vp-p (H)
		Julyulu,	
0.9 Vp-p (H)	1.6 Vp-p (H)	1.3 Vp-p	3.2 Vp-p (H)
18	พหรัพหรืนทาน อ		

3.2 Vp-p (H)




3.2 Vp-p (H)




- Carrier Clagrams

D F1 F2


← H1 H2 boards





TU, AU,
CHANNEL SELECTION,
COLOR SYSTEM,
SUB HUE, MUTE


### A Board IC304 CXA1587S



### • A BOARD

IC	Q104 E-9 Q105 E-6	Q312 D-1 Q313 B-9	D204 C-9 D205 B-9	IF BLOCK
IC001 B - 2 IC002 C - 3 IC003 C - 1	Q106 E-6 Q107 A-9 Q108 D-6	Q314 A - 9 Q315 E - 3 Q316 A - 9	D206 B - 9 D207 C - 9 D208 C - 9	IF101 D-6
IC101 D-6	Q109 D-9 Q110 D-9	Q317 A-9 Q318 A-8	D209 C-9 D210 D-9	TUNER
IC201 C-9 IC202 B-6 IC203 D-5	Q111 D-9 Q112 E-9 Q113 E-9	Q564 B - 5 Q565 B - 5 Q566 C - 5	D211 D-9 D212 D-9 D213 C-8	TU101 E-9
IC301 E-3	Q201 B-9 Q202 B-8	DIODE	D214 C-8 D215 C-8	CRYSTAL
IC302 E - 4 IC304 D - 2 IC305 A - 2 IC561 C - 5 IC563 B - 5 IC564 B - 4 IC682 A - 7 IC683 B - 6 IC684 B - 6	Q202 B - 8 Q203 B - 8 Q204 C - 7 Q205 D - 5 Q206 B - 9 Q207 B - 8 Q208 C - 7 Q209 D - 6 Q210 D - 5 Q303 C - 2	DIODE  D001 B - 2 D004 C - 1 D005 E - 1 D016 E - 1 D068 C - 1 D077 C - 1 D078 C - 1	D216 C - 8 D217 C - 8 D218 D - 5 D301 D - 3 D302 E - 5 D303 E - 2 D304 E - 4 D305 C - 2 D306 D - 2	X001 C - 3 X301 E - 3 X302 E - 2
TRANSISTOR	0004 0 0	D079 C-1 D101 E-7	D307 C-2 D308 C-2	
Q002 E-1 Q003 B-3 Q101 D-9 Q102 E-8 Q103 E-9	Q307 A - 1 Q308 D - 2 Q309 C - 2 Q310 A - 2 Q311 D - 1	D102 E - 6 D103 D - 6 D201 8 - 9 D202 B - 9 D203 B - 9	D311 C-3 D312 C-2 D313 C-2 D381 D-1 D571 E-2	


PRINTED WIRING BOARDS
- A Board -



## KV-K29CF1 RM-845P

VM [VM OUT]


PRINTED WIRING BOARDS
- VM Board -



A2 [R, G, B IN/OUT, SCP IN/OUT]


**P** [P IN P]

- A2 Board -



### • P BOARD

IC	Q1403 Q1404	C-1 C-1	DIODE
IC1401 C-2 IC1402 B-2 IC1403 A-3	Q1405 Q1406 Q1407	C-1 B-3	D1400 B-2 D1401 B-1
IC1404 B - 3 IC1405 B - 4	Q1408 Q1409	B-3 B-3	CRYSTAL
IC1406 C - 4 IC1407 C - 3 IC1410 C - 3	Q1413 Q1414 Q1416	C-4 C-4	X1401 C-1 X1402 C-1
TRANSISTOR	Q1417 Q1418	B-3 B-2	
01401 C-1	Q1419 Q1420 Q1421	B-3	
Q1402 B-1	Q1422	C-4 C-4	



PAL SECAM NYSC3.58

0.4 Vp-p (H)

1.5 Vp-p (H)

NTSC4.43

0.4 Vp-p (H)

mondey

1.3 Vp-p (H)

• P BOARD WAVEFORMS

2.0 Vp-p (H)

NTSC4.43

0.4 Vp-p (H)


1.3 Vp-p (H)


(3)


PAL SECAM NYSC3.58

0.4 Vp-p (H)

1.5 Vp-p (H)











AF SI TO . C Ct


8 | 9 | 10 | 11 | 12 | 13 | 14 | 15 | 16 | 17 | 18 | 19 | 20 | 21 | 22 | 23 | 24 | 25 | 26 | 27 | 28



























A 2 P VM boards





### • C BOARD WAVEFORMS






PIT ROTATION CIRCUIT,
V-PIN CORRECTION,
PICTURE ROTATION CONTROL,
V-PIN CONTROL

### PRINTED WIRING BOARDS

- D1 Board -




### • D1 BOARD

IC	Q1851 C-3 Q1854 C-2	D1856 C-3 D1864 C-2
IC1804 C-1 IC1851 C-3 IC1852 C-3 IC1853 C-2	Q1855 C-2 Q1856 B-2 Q1857 B-2 Q1858 B-2	D1867 B - 2 D1868 B - 2 D1882 C - 3 D1883 B - 2
TRANSISTOR	Q1859 C-2 Q1860 C-2 Q1861 C-2	VARIABLE RESISTOR
Q1812 B-1 Q1813 B-1 Q1814 B-1	DIODE	RV1801 C - 2 RV1853 C - 4
Q1815 B-1 Q1816 A-1 Q1817 A-1 Q1818 C-1 Q1840 B-3 Q1841 B-4	D1804 B - 1 D1819 B - 1 D1820 B - 1 D1821 A - 1 D1840 B - 4 D1841 B - 3	

C [R, G, B OUT]

- C Board -





### NOTE:

The circuit indicated as left contains high voltage of over 600 Vp-p. Care must be paid to prevent an electric shock in inspection or repairing.

### 5-5. SEMICONDUCTORS


CAT24C04P LM358P LM393P SDA9086-3  $\mu$  PC358C  $\mu$  PC393C








CXD2018Q



CXK5864BSP-10L MAB8461P-W220 SAA5231/V7 SDA9187X SDA9188X



CXP80424 CXP80424-SV4652



(Top view)

HZT33-02TE  $\mu$  PC574J



LA7016



LM358PS



L78LR05D-MA




MC78L05ACPRP NJM78L05A



MC7809CT MC7812CT NJM78M09FA TA7805S μ PC7805H



PQ05RF1




SAA5243P/T



(Top view)





SN74LS221N TDA4661/V2 TDA9821



STR-81145A



TA8200AH



TA8776N



TDA8204 TDA8205




(Top view)






TDA9160A



TDA9840



DTA114EK DTA144EK DTC114EK DTC114EK 2SA1037K 2SA1162-G 2SC1623-L5L6 2SC2412K 2SC2412K-QR 2SC2413KQ



DTC114ES DTC144ES



2SA1091-O 2SC2551-O



2SA1175-HFE 2SA1309A 2SC2785-HFE 2SC3311A



2SA1315-Y



2SA1837



2SB734-34 2SC2958-L 2SD774-34



2SB858-C 2SB860 2SD2012 2SD2061-EF











2SC3298B-O 2SC4793 2SD1137



2SC4927-01




DAN202K




DAP202K



DA204K



D4SB60L




EGP20G EG01 EL-1Z EU-1Z EU-2 GP08D RGP15G RGP15J




ERA82-004 ERA85-009 HZS5CLL-TD RD10ES-B3 RD3.6ES-B1 RD39ES-B2 RD5.1ES-B2 RD5.1ES-B1 RD5.1ES-B1 RD5.6ES-B RD7.5ES-B1 RD7.5ES-B1 RD7.5ES-B1 RD7.5ES-B2 RD7.5ES-B3 RD9.1ESL 1SS119 1SS1133




ERC06-15S RGP02-20EL-6394



ERD29-08J RGP02-17 RGP02-17EL-6433 RU4AM RU4DS





GP08 U05G



MA3047 RD13M-B2 RD3.6M-B2 RD4.7M-B2 RD5.6M-B3 RD6.8M-B1





MA3051L-TX



PC111LS PC111YS








### 6-1. CHASSIS

●: BVTP3 × 12 7-685-648-79


■: BVTP4 × 16 7-685-663-79



### 6-2. PICTURE TUBE

⊕: BVTP3 × 12 7-685-648-79
 ▲: BVTP4 × 12 7-685-661-14

: BVTP4 × 16 7-685-663-79



# G3F CHASSIS

<u>MODEL</u>	COMMANDER	DEST.	CHASSIS NO.	MODEL	COMMANDER	DEST.	CHASSIS NO.
KV-K21MN11	RM-845T	ME EX	SCC-G37B-A SCC-G50A-A	KV-K29MH11	RM-845	HK (Serial No.	SCC-G43A-A 1,025,772 and later)
KV-K25MN11	RM-845P	ME (Serial No. EX	SCC-G37A-A 1,002,051 and later) SCC-G50B-A	KV-K29MN11	RM-845P	GE (Serial No.	SCC-G44A-A 1,021,151 and later)

# **SUPPLEMENT-4**

SUBJECT: 1. CHANGE OF F2 BOARD

2. CHANGE OF IC601 ON D BOARD

File this supplement with the service manual.

#### Note:

- All capacitors are in μF unless otherwise noted. pF: μμF 50 WV or less are not indicated except for electrolytic and tantalums.
- All resistors are in ohms.
   kΩ =1000Ω, MΩ =1000ΚΩ
- Indication of resistance, which does not have one for rating electrical power, is as follows.

Pitch: 5 mm Rating electrical power 1/4 W (CHIP: 1/10W)

- nonflammable resistor.
- \_\_\_\_\_\_: panel designation, or adjustment for repair.
- All variable and adjustable resistors have characteristic curve B, unless otherwise noted.
- Readings are taken with a color-bar signal input.

no mark: PAL

>: SECAM

): NTSC 3.58

( ): NTSC 4.43

- Readings are taken with a 10 MΩ digital multimeter.
- Voltage are dc with respect to ground unless otherwise noted.
- Voltage variations may be noted due to normal production tolerances.
- All voltages are in V.
- \* : Can not be measured.
- Circled numbers are waveform reference.

• B + bus.

• : signal path.

Note: The components identified by shading and mark

⚠ are critical for safety. Replace only with part
number specified.

### Reference information

RESISTOR	: RN	METAL FILM
	: RC	SOLID
	: FPRD	NONFLAMMABLE CARBON
	FUSE	NONFLAMMABLE FUSIBLE
	: RS	NONFLAMMABLE METAL OXIDE
	: RB	NONFLAMMABLE CEMENT
	: RW	NONFLAMMABLE WIREWOUND
	: 💥	ADJUSTMENT RESISTOR
COIL	: LF-8L	MICRO INDUCTOR
CAPACITOR	: TA	TANTALUM
	: PS	STYROL
	: PP	POLYPROPYLENE
	: PT	MYLAR
	: MPS	METALIZED POLYESTER
	: MPP	METALIZED POLYPROPYLENE
	: ALB	BIPOLAR
	: ALT	HIGH TEMPERATURE

HIGH RIPPLE



# G3F CHASSIS

(Serial No. 1,023,851 and later)

MODEL MODEL COMMANDER DEST. CHASSIS NO. COMMANDER DEST. CHASSIS NO.

SCC-G37A-A

ME

KV-K21MN11 RM-845T KV-K29MH11 RM-845 SCC-G37B-A ME SCC-G43A-A HK SCC-G50A-A ΕX (Serial No. 1,026,272 and later)

(Serial No. 1,426,272 and later) KV-K25MN11 RM-845P

EΧ SCC-G50B-A KV-K29MN11 RM-845P GE SCC-G44A-A (Serial No. 1,020,451 and later)

# **SUPPLEMENT-6**

SUBJECT 1: CHANGE OF PICTURE TUBE

2: CHANGE OF COMPONENT VALUE ON VM AND D BOARDS

File this supplement with the Service Manual.

#### INTRODUCTION:

• On KV-K29MH11/KV-K29MN11 listed above shows 2 lines of serial numbers. The serial numbers on the first line are the sets with the new CRTs. Those on the second line are the sets with the new VM boards.

PART NO. **DESCRIPTION** PICTURE TUBE (KV-K29MN11 GE only) △ 8-733-866-05 PICTURE TUBE (KV-K29MH11 HK only)

### PARTS CHANGE: VM BOARD

REF. NO.	PARTS NO.	DESCRIPTION				REMARK
C1751	1-102-107-00	CERAMIC	120PF	10%	50V	
C1752	not mount					
D1765	not mount					
D1766	not mount					
JW213	1-249-393-11	CARBON	10	5%	1/4W	
Q1767	8-729-142-86	TRANSISTOR 2SC	3733			
R1774	1-215-912-11	METAL OXIDE	150	5%	3W	F
R1753	1-249-421-11	CARBON	2.2K	5%	1/4W	
R1783	1-535-303-00	LEAD, JUMPER (5.0	OMM)			
R1788	1-249-417-11	CARBON	1.0K	5%	1/4W	

### PARTS CHANGE: D BOARD

REF. NO.	PARTS NO.	DESCRIPTION				<u>REMARK</u>
C2519	1-136-611-11	FILM	16000PF	3%	1.4KV	
C2548	1-161-754-00	CERAMIC	1000PF	10%	3KV	



# G3F CHASSIS

KV-K21MN11 RM-845T ME SCC-G37B-A KV-K29MH11 RM-845 HK SCC-G43A-A KV-K21MN11 RM-845T EX SCC-G50A-A KV-K29MN11 RM-845P GE SCC-G44A-A KV-K25MN11 RM-845P ME SCC-G37A-A	•	MODEL	COMMANDER	DEST.	CHASSIS NO.	MODEL	COMMANDER	DEST.	CHASSIS NO.
KV-K25MN11 RM-845P EX SCC-G50B-A		KV-K21MN11 KV-K25MN11	RM-845T RM-845P	EX ME	SCC-G50A-A SCC-G37A-A				

# **CORRECTION-2**

SUBJECT: PART CHANGE

File this correction with the Service manual.

INTRODUCTION: Corrected the FBT part no. (KV-21MN11 only)

:Indicates corrected portion

**SECTION 6. EXPLODED VIEWS** 

6-1.CHASSIS (See page 70)

REF NO. PART NO. DESCRIPTION

A 8-558 COSCO TRANSFORMER RYBACK (MACADOMANA) (V-12-14) (11 cm)

**ELECTRICAL PARTS LIST** 

D BOARD (See page 90)

REF NÓ. PART NO.

DESCRIPTION

A 8-550-826-00 TRANSFORMER, FLYBACK (NX-SEDVANSA)(NX-SEDV

MICROFILM

**※** Please file according to model size. ..........

21

25

29

Sony Corporation
Display Company
Quality Engineering Dept.

# G3F CHASSIS

MODEL	COMMANDER	DEST.	CHASSIS NO.	MODEL	COMMANDER	DEST.	CHASSIS NO.
KV-K21MN11	RM-845T	ME EX	SCC-G37B-A SCC-G50A-A	KV-K29MH11	RM-845 (Serial No. 1,02		SCC-G43A-A and later)
KV-K25MN11	RM-845P	ME EX	SCC-G37A-A SCC-G50B-A	KV-K29MN11	RM-845P (Serial No. 1,01	GE 19651 a	SCC-G44A-A and later)

## **SUPPLEMENT-5**

SUBJECT KV-K29MH11, KV-K29MN11

1: CHANGE OF PICTURE TUBE

2: CHANGE OF D1 BOARD

3: CHANGE OF NECK ASSY AND DY

File this supplement with the Service Manual.

### INTRODUCTION:

On KV-K29MH11/KV-K29MN11 the following new parts numbers are introduced to the models serial numbers listed above and later.

<u>PART NO.</u>	<u>DESCRIPTION</u>
A 8-733-859-05	PICTURETUBE
A-1346-473-A	D1 BOARD COMPLETE
<b>Д 1-452-762-31</b> <b>Д 8-451-467-21</b>	NECK ASSY PICTURE TUBE (NA294) DEFLECTION YOKE (Y29GX2A)

### Note on replacement of CRT:

- For those sets prior to the serial numbers listed above, be sure to use the picture tube: 8-733-854-05 for replacement.
- Especially on replacing CRTs of the following serial numbers sets, check if the label on the tube shows 9GB and if no tape is applied around the CRT neck of the Neck Assy. In this case, be sure to replace the Neck Assy with 1-452-509-12 at the same time as the CRT.

MODEL

<u>DEST.</u> HK SERIAL NO.

KV-K29MH11

1,025,703 to 1,025,771



# G3F CHASSIS

MODEL COMMANDER DEST.	CHASSIS NO.	MODEL	COMMANDER	DEST.	CHASSIS NO.
W/ KOEMMI11		KV-K29MH11 KV-K29MN11			SCC-G43A-A SCC-G44A-A

## **SUPPLEMENT-7**

SUBJECT: PART CHANGE

File this supplement with the Service manual.

INTRODUCTION: Change the CRT part no. (KV-K29MH11/K29MN11 only)

:Indicates changed portion

**SECTION 6. EXPLODED VIEWS** 

6-2.PICTURE TUBE (See page 71)

REF NO. PART NO. DESCRIPTION

60 A \$700 COSC PICTURE (NEXC277)()(CACCOMMI)

A \$700 COSC PICTURE (NEXC277)()(CACCOMMI)

ELECTRICAL PARTS LIST MISCELLANEOUS (See page 94)

REF NO. PART NO. DESCRIPTION

VOI A 4723-00-05 RETURE (MONZT71X)AN-KONA(III)

A 5723-00-05 RETURE TUBE (MONZT71X)AN-KONA(III)

MICROFILM

9-965-527-87

21

25

29

Sony Corporation
Display Company
Quality Engineering Dept.